

CHAPTER 4.4.

RECOMMENDATIONS FOR SURFACE DISINFECTION OF SALMONID EGGS

Article 4.4.1.

Introduction

The practice of disinfecting salmonid *eggs* at hatcheries is an essential part of ensuring that *pathogenic agents* are not transferred between incubators and between facilities and forms a part of routine hatchery hygiene protocols. The *disinfection* process is also important for *international trade* in salmonid *eggs* between countries, *zones* or *compartments* to prevent the transfer of some *pathogenic agents*. Although generally effective for *disinfection* of the *egg* surface and reproductive fluids, the use of *disinfectants* will not prevent vertical transmission.

Salmonid *eggs* may be disinfected with a number of chemical agents. However, the most common method used is *disinfection* with the iodine-based product, povidine-iodine.

Iodophores, commonly povidone-iodine solutions, have the advantage of providing a neutral pH, being non-irritant and are relatively non-toxic. The neutral pH is important for minimising toxicity and ensuring efficacy. It is recommended to follow manufacturer's instructions to identify circumstances where pH may be a concern. If other iodine based agents are used for *disinfection* it is essential that they be adequately buffered.

Article 4.4.2.

Disinfection protocol for salmonid eggs

This *disinfection* protocol may be applied to newly fertilised or eyed salmonid *eggs*. However newly fertilised *eggs* should be allowed to commence hardening prior to undergoing the *disinfection* protocol. Although there is a considerable margin of safety for hardened *eggs*, the *disinfection* protocol is not recommended for unfertilised ova or during fertilisation. It is essential that the pH of the iodophore solution is maintained between 6 and 8.

To disinfect salmonid *eggs* the following protocol should be applied:

- 1) rinse in pathogen-free 0.9% to 1.1.% saline (30-60 seconds) to remove organic matter; then
- 2) immerse in an iodophore solution containing 100 ppm available iodine for a minimum of 10 minutes. The iodophore concentration should be monitored to ensure effective levels are maintained. The ratio of *eggs* to iodophore solution should be a maximum of 1:4; then
- 3) rinse again in pathogen-free 0.9% to 1.1.% saline for 30-60 seconds; then
- 4) hold in pathogen-free water.

All rinsing and *disinfection* solutions should be prepared using pathogen free water. Iodophore solutions may be buffered using sodium bicarbonate (NaHCO₃) if the pH is low.

NB: FIRST ADOPTED IN 2015; MOST RECENT UPDATE ADOPTED IN 2017.

